

PB1.01	Display Lights Wires - Complete Set	35.00
PB1.04	Coin Acceptor Cable	10.00
PB1.06	Punch Bag Penalty - Complete Set	150.00
PB1.07	Punch Bag Boxer - Leather Only	100.00
PB1.08	Punch Bag - Inflatable Insert	8.00
PB1.09	Punch Bag Penalty - Rubber Attach.	35.00
PB1.10	Arm Protector/Safety Cover	15.00
PB1.11	Power Plug and Switch	15.00
PB1.12	Power Transformer	65.00
PB1.13	Start Button	15.00
PB1.14	Power Board	250.00
PB1.15	Display Board NEW	250.00
PB1.16	Coin Acceptor - Comestero RM5	165.00
PB1.17	Apex 5000 Bill Acceptor	240.00
PB1.18	Halogen Lamp - MR11	10.00
PB1.19	Display Lights Lamp - L28 (Box of 10)	10.00
PB1.20	Optic Sensor	25.00
PB1.21	Release Mechanism - Complete Set	300.00
PB1.24	Large Display Glass - Boxer	150.00
PB1.25	Game Mode Selection Glass (Oval)	35.00
PB1.26	Plastic Face Plate Alex 5000	15.00
PB1.27	Wheel	15.00
PB1.28	Coin Container	15.00
PB1.29	Lock and Keys Set	18.00
PB1.32	Roof-top Cover	150.00
PB1.33	Drain Pipe	5.00
PB1.34	Halogen Lamp Holder MR11	5.00
PB1.35	Halogen Lamp Connector MR11	5.00
PB1.36	Plastic Faceplate Coin Acceptor	12.00
PB1.37	Metal Face Plate Apex	18.00
PB1.38	Power Cord	7.00
PB1.39	Sensor Bolt	5.00
PB1.40	Fuses (Box of 10)	10.00
PB1.41	Graffiti Stickers	60.00
PB1.42	Foam Cushion	14.00
PB1.43	Large Stopper	10.00
PB1.44	Small Stopper	7.00
PB1.45	CPU Board	300.00
PB1.46	Punch Bag Boxer - Complete Set	135.00
PB1.47	Electronic Board Set plus Wiring	1,080.00
PB1.49	Punch Bag Penalty - Leather Only	110.00
PB1.50	Bag for Insert	5.00
PB1.51	Electric Motor - Solenoid	15.00
PB1.52	Punch Bag Boxer - Rubber Attach.	35.00
PB1.53	Set of ribbon, cable, wire	15.00
PB1.59	Large Service Door	60.00
PB1.60	Coin Container	10.00

PB1.71	Penalty- Round Safety	30.00
PB1.72	Penalty- Safety Cover	55.00
PB.1.68	Manual for BOXER arcade machine	0.00